

# INSTALLATION INSTRUCTIONS

## PROJECT PREMIUM BATHS

J5115A - 1500 Bath  
J5116A - 1675 Bath

### PROCEDURE

Check that your floor is level and secure. The bath does not need to be supported by a mortar bed.

The bath rim must be fully supported - timber or masonry supports must have full contact with floor to achieve correct support for bath (DIAGRAM 1).

Install rim supports then run a generous bead of silicone along the top of the support, fit the bath and allow sufficient time to cure.

If the bath is being checked into an adjoining wall, make sure that the wall is rebated to a depth that will permit the tiling lip to be checked in (DIAGRAM 2).

